


## Helical Bar Repair of Cracks at Junctions of Solid and Cavity Walls



### METHOD STATEMENT

1. Rake out or cut slots into horizontal mortar joint to specified depth and at required vertical spacing.
2. Vacuum out the slots and thoroughly flush with water.
3. Using the grout gun insert a bead of cementitious grout into the back of the slot.
4. Push the helical bar reinforcement into the grout to obtain good coverage.
5. Insert a bead of cementitious grout over the exposed helical bar and iron into the slot using the finger trowel.
6. Point up or fill the joint and leave ready for any decoration.

### GUIDANCE NOTES *Unless otherwise specified, the following criteria are to be used:*

- a. Depth of slot to be 35 mm.
- b. Normal vertical spacing of helical bars is 300 mm (4 brick courses).
- c. Helical bar to extend a minimum of 500 mm each side of the crack.

*To find out more and to see how we could help you, please contact us*

[info@quadrabuild.com](mailto:info@quadrabuild.com) | 02086 445 434 | [www.quadrabuild.com](http://www.quadrabuild.com)

