




## Helical Tie Installation into Side of Joist



## METHOD STATEMENT

1. Locate and mark the positions of joists on the external wall.
2. Drill clearance hole (normally 12 mm) through masonry in line with the centre of the joists.
3. Ensure that the hole lines up with the joist and continue to drill the hole through the first joist.
4. Blow out hole to clear any dust or debris.
5. Place support tool over the helical tie and drive the tie into the second joist for a minimum depth of 50 mm.
6. Inject resin or cementitious grout into the hole to completely fill it.
7. Make good at surface of all holes and leave ready for any decoration.

## GUIDANCE NOTES *Unless otherwise specified, the following criteria are to be used:*

- a. Minimum penetration into the timber is 50 mm.
- b. Horizontal spacing is 600 mm between ties.

*To find out more and to see how we could help you, please contact us*

[info@quadrabuild.com](mailto:info@quadrabuild.com) | 02086 445 434 | [www.quadrabuild.com](http://www.quadrabuild.com)

